



SOLVAY

asking more from chemistry®

Multiscale approach for continuous crystallizer revamp

APMF - Apr 2016

We are a world leader in the chemical industry



26,000
employees



119
industrial sites



15
major
R&I centers



52
countries




€ 10,213
million of net sales



€ 1,783
million of REBITDA


2014 figures

We adapt our product offering to **demanding** markets



Distribution
of 2014 net sales

Limitation of the plant production capacity



Objective: Production increase

with limited Investments

- Modification of the current separation system
 - ➔ tests of different operating conditions and filtration medium: No success ☹
 - ➔ A new liquid / solid separation technology has been found, but it is expensive and there are still some technical risks



Improvement of the feed quality

➔ Work on the crystallization operation !


Controlling Crystal's filter-ability

Multiscale approach

1. Experiments at lab scale
2. Crystallization modelling within gCRYSTAL – Lab scale
3. Simulation of the industrial crystallizer
4. Input of the CFD / gCRYSTAL Multizonal
5. Optimization of the crystallizer design and operating parameters

Lab scale experiments

Pilote-scale MSMPR - continuously operated crystallizer



Parameters:

- $T_{\text{cryst.}}$
- $T_{\text{feed.}}$
- τ_{res}
- C_{solid}
- ω

1. Experiments

2. Lab. model


3. Indus. model

4. CFD Input

5. Optimization

Modelling continuous crystallization

Lab scale



1. Experiments

2. Lab. model

3. Indus. model

4. CFD Input


5. Optimization

Crystallization kinetics

2ndary nucleation

1 - Activated secondary nucleation


$$J_{\text{sec}} = A_t \left[\exp(\ln k_s) \frac{D_{AB}}{d_m^4} \exp \left(-\pi \left(K \ln \left(\frac{c_c}{c^*} \right) \right)^2 \frac{1}{\nu \ln S_a} \right) \right]$$



Periodic regime

2 - Attrition

$$J_{\text{sec ci}} = \exp(\ln k_{n-ci}) \sigma^{n_{ci}} \frac{N_Q}{N_P} k_v \rho_c \varepsilon \int_{L_{\min-ci}}^{\infty} n L^3 dL$$



Stable regime

1. Experiments

2. Lab. model

3. Indus. model

4. CFD Input

5. Optimization

Crystallization kinetics

Growth & Agglomeration

1 – Crystal growth

power law kinetic

$$G = k_g \exp\left(\frac{-E_{A,g}}{RT}\right) \sigma^g$$

2 – Agglomeration

not in the initial model, because its effect can be difficult to distinguish from crystal growth

1. Experiments

2. Lab. model

3. Indus. model

4. CFD Input

5. Optimization

Parameter estimation

set-up

Choosing the experiments

Experiment	Include in estimation
A14M0019_RP	<input type="checkbox"/>
A14LS0019_RP_1	<input checked="" type="checkbox"/>
A14LS0033_RP	<input checked="" type="checkbox"/>
A14LS0034_RP	<input checked="" type="checkbox"/>
A14LS0036_RP	<input type="checkbox"/>
A14LS0037_RP	<input checked="" type="checkbox"/>
A19LS0007_RP	<input type="checkbox"/>
A19LS0011_RP	<input checked="" type="checkbox"/>
A19LS0014_RP	<input checked="" type="checkbox"/>
A19LS0017_RP	<input checked="" type="checkbox"/>

Error in each measurement

Set the variance model for the group.

Variance model: Constant variance


Parameter	Initial guess	Fixed?	Lower bound	Upper bound
ω	30.0	<input checked="" type="checkbox"/>	30.0	30.0

OK Cancel

Kinetic parameters I.C. & boundaries

Parameter to be estimated	Initial guess	Fixed?	Lower bound	Upper bound
crystalliser_MSMPR001 → Agglomeration parameter (A50) ("AA_crystal")	0.0	<input checked="" type="checkbox"/>	0.0	0.0
crystalliser_MSMPR001 → Activation energy ("AA_crystal")	2500.0	<input checked="" type="checkbox"/>	2500.0	2500.0
crystalliser_MSMPR001 → Growth rate constant ("AA_crystal")	10.0	<input type="checkbox"/>	1.0	50.0
crystalliser_MSMPR001 → Order with respect to supersaturation ("AA_crystal")	1.0	<input type="checkbox"/>	0.0	2.0
crystalliser_MSMPR001 → Rate constant ("AA_crystal")	9.0	<input checked="" type="checkbox"/>	9.0	9.0
crystalliser_MSMPR001 → Slurry density order ("AA_crystal")	2.0	<input checked="" type="checkbox"/>	2.0	2.0
crystalliser_MSMPR001 → Specific power input order ("AA_crystal")	1.0	<input checked="" type="checkbox"/>	1.0	1.0
crystalliser_MSMPR001 → Supersaturation order ("AA_crystal")	2.0	<input checked="" type="checkbox"/>	2.0	2.0
Add new				

Running the optimization routine



1. Experiments

2. Lab. model


3. Indus. model

4. CFD Input

5. Optimization

Simulations vs Experiments

Good Fit at lab scale



1. Experiments

2. Lab. model


3. Indus. model

4. CFD Input

5. Optimization


Simulation of the industrial crystallizer

real operating conditions




- Real dimensions, operating conditions etc.
- Kinetics from lab data

Simulation with Lab kinetics



Bad fit !

Identification of industrial kinetics



1. Experiments

2. Lab. model

3. Indus. model

4. CFD Input

5. Optimization

Test of new operating conditions

Discrepancy between simulation and industrial test

Modification of the temperature conditions



Test at industrial scale



Bad fit with the simulation and
No real Improvement !

1. Experiments

2. Lab. model

3. Indus. model


4. CFD Input

5. Optimization

Using CFD simulation in g-CRYSTAL


g-CRYSTAL Multizonal

CFD simulation




1 crystallization stage

Choosing the « Zones »



Extraction of CFD data



1. Experiments

2. Lab. model


3. Indus. model

4. CFD Input

5. Optimization

MSMPR vs Multizonal

Small difference with the simple model




1. Experiments 2. Lab. model 3. Indus. model **4. CFD Input** 5. Optimization

Model improvement


Agglomeration mechanism

Mumtaz Agglomeration kernel

$$\beta_{agg} = \left(\sqrt{\frac{8\pi\varepsilon}{15\nu}} \cdot \bar{d}_{3.0}^3 \right) \cdot \frac{(A_{50}G)/(\varepsilon\rho\bar{d}_{3.0}^2)}{1 + (A_{50}G)/(\varepsilon\rho\bar{d}_{3.0}^2)}$$



Non linear behaviour



1. Experiments

2. Lab. model


3. Indus. model

4. CFD Input

5. Optimization

Effect of the hydrodynamic

Industrial scale



1. Experiments

2. Lab. model


3. Indus. model

4. CFD Input

5. Optimization

Better fit with the Multizonal Crystallizer

Industrial Scale



1. Experiments 2. Lab. model 3. Indus. model **4. CFD Input** 5. Optimization


Designing Crystallizer Modifications

DOE Approach


1.
 - Inlet position
 - Impeller geometry
 - Average Power Input ϵ




2^3 DOE



2. Monophasic CFD Simulations




Multizonal Simulations



3. Analysis of the DOE



Best set of modifications



1. Experiments

2. Lab. model


3. Indus. model

4. CFD Input

5. Optimization

Capacity increase after modifications

At low investment



+

ε



Narrower CSD



Higher filter-ability

We achieved a 25% increase in filtration capacity

1. Experiments

2. Lab. model

3. Indus. model

4. CFD Input

5. Optimization

Conclusions

- CFD + Population Balance Modeling is a very efficient tool for
 - Optimizing existing crystallizer ➔ reduce experimental costs (time and money !)
 - Designing New equipments ➔ Allow the implementation of breakthrough technologies

& Future Work

- A purification model can be extracted from the population balance

$$C_i = f(r_{N2}, G, Agg)$$



optimization with the same model

Acknowledgments



Niall Mitchell
Sean Bermingham
Hassan Mumtaz
David Slade



N. Perret
L. Scali
E. Chateigner

Thank You for your Attention !