

DESIGN OF A BATCH FERMENTATION PROCESS

DESIGN OPTIMISATION OF A
BATCH FERMENTATION
PROCESS IN A CONTINUOUS
INFANT MILK PLANT

Martijn van der Hoeven, PhD

London, 2 April 2014

OUTLINE

Information Nutricia Research

Project background

Modelling setup and results

CURRENT GROUP DANONE

“Bringing health through food to as many people as possible”



€4.3 billion
+3.6% growth in 2013
Early Life Nutrition



€11.8 billion
+3.2% growth in 2013
Fresh Dairy Products



€ 3.9 billion
+11.2% growth in 2013
Waters



€1.3 billion
+5.8% growth in 2013
Medical Nutrition



PROCESSING & NEW TECHNOLOGIES PLATFORM: POWDER PROCESSING TEAM


Team mission:

- Process development for new products
- Obtaining mechanistic process understanding
- Process optimisation projects
- Supporting supply points worldwide
- Supporting Food Science & Technology lab and Pilot Plant



THE JOURNEY FROM INGREDIENTS TO CUSTOMER

Continuous production process



Mastering production process is key for superior quality (safety, nutrition and easy-of-use) at acceptable costs


PROBLEM DESCRIPTION



CONTINUOUS



BATCH



CONTINUOUS

UNIQUENESS OF CASE

Normally gPROMS used to optimise single batch process

- Controlling reaction kinetics
- Finding rate limiting steps

Nutricia case:

- Optimising several batch process running in parallel
- Fit in batch process to allow continuous up stream and down stream processes
- Check operability / robustness of process design
- Evaluate usefulness of gPROMS for business
 - R & D
 - Operations / engineering

MORE DETAILS



CONTINUOUS
Fixed flow rate



Fixed filling time



Fixed fermentation time




Fixed storage time



Fixed emptying time

BATCH



CONTINUOUS
Fixed flow rate

filling flow rate > emptying flow rate

QUESTIONS

How many fermenters of which size are needed to maintain continuous flow to spray dryer?

When to switch evaporator on/off for cleaning?

- Minimise number of on/off cycles
- Limited uptime of single evaporator before cleaning required


What is available redundancy / sensitivity to disturbances?

CONSTRAINTS




**evaporator running:
fermenter available**

**evaporator must run
until fermenter is full**




**always flow from
fermenter to spray dryer**



**spray dryer is expensive:
must be rate limiting**


START UP

- No flow from evaporator
- No flow to spray dryer
- All fermenters empty



FIRST CYCLE

FERMENTER 1
fill fermenter




FIRST CYCLE

FERMENTER 1

ferment fermenter

FERMENTER 2

fill fermenter



FIRST CYCLE

FERMENTER 1


empty fermenter

FERMENTER 2

ferment fermenter

FERMENTER 3

fill fermenter



FIRST CYCLE

FERMENTER 1

clean fermenter

FERMENTER 2



empty fermenter

FERMENTER 3

ferment fermenter

FERMENTER 4

fill fermenter



FIRST CYCLE

FERMENTER 1

**Ready for
next round**

FERMENTER 2


clean fermenter

FERMENTER 3

empty fermenter


FERMENTER 4

ferment fermenter



COMPLICATION... SINGLE FERMENTER


$t_{\text{filling}} \neq t_{\text{fermenting}} \neq t_{\text{emptying}} \neq t_{\text{cleaning}}$



COMPLICATIONS... MULTIPLE FERMENTERS


Complicated batch scheduling

- Batch process itself does not need to be optimised (fixed)
- Scheduling of several batch process simultaneous needs to be optimised




MODELLING APPROACH

- Introduce 'Scheduler' model
 - Allocates resources based on 'state' of each fermenter
- Use gPROMS tasks in parallel to control fermenters and evaporator
- Simulate over long time horizon to capture many cycles




MODELLING APPROACH

- Flow to fermenters directed by Splitter model
- Flow to spray dryer directed by Mixer model
- Only allowed inlet/outlet from a single fermenter




MODELLING APPROACH - SPLITTER

- Only allowed to fill one fermenter at a time
- If no fermenter is idle then the evaporator will be stopped
- If multiple fermenters are idle then will fill vessel which has been idle shortest amount of time
 - Some fermenters could remain unused



MODELLING APPROACH - MIXER

- Only allowed inlet from a single fermenter
- If no fermenter is ready
 - stop spray dryer
- If multiple fermenters are ready
 - choose vessel with longest t_{storage}



MODELLING APPROACH - FERMENTER

- Fermenter model has dynamic mass holdup
- Can be in one of six states
 - Idle
 - Filling
 - Fermenting
 - Storing
 - Emptying
 - Cleaning
- State changed by tasks
- Model tracks length of time for which it has been storing a given load

MODEL OVERVIEW

PARALLEL

evaporator

up- and down time

splitter

control splitter

mixer

control mixer

fermenter

initialise + fill

ferment


store

empty tank with
longest storage

clean

idle

MODELLING RESULTS - EVAPORATOR




scheduler (scheduler)

tanks to fill before stopping evaporator flow:

When to restart evaporator flow:

Specify

- ☒ Simulation time: hr
- ☒ Cleaning time: hr
- ☒ Fermentation time: hr
- ☒ Filling time: hr



scheduler (scheduler)

tanks to fill before stopping evaporator flow:

When to restart evaporator flow:

Specify

- ☒ Simulation time: hr
- ☒ Cleaning time: hr
- ☒ Fermentation time: hr
- ☒ Filling time: hr

EVAPORATOR RUN TIME OPTIMISATION

Evaporator run time

- $n \cdot t_{\text{filling}}$





Evaporator cleaning time

- $n \cdot (t_{\text{emptying}} - t_{\text{filling}})$

Example: 4 fermenters / cycle, $\Delta t = 1$ h, $t_{\text{filling}} = 3$ h

- Uptime / downtime: 12 h / 4 h
- Optimising by gProms: 15 h / 5 h

ROBUSTNESS - CLEANING TIME / DOWNTIME



MODELLING RESULTS – # FERMENTERS

What is the minimum number of fermenters needed to run continuous?

- Only variable: cleaning time $\rightarrow t_{\text{cleaning}} = 0 \text{ h} \rightarrow 4 \text{ fermenters}$
- No possibility to have < 4 fermenters
- Maximum cleaning time, before needing 5 fermenters: 4 h
- Longer fermenter cleaning time is possible
 - Run time evaporator decreases
 - Cleaning time evaporator decreases


MODELLING RESULTS – STORAGE TIME

Storage time of fermented products is important

- viscosity increases over time
- storage time should be limited
- holding time = storage time (full tank) + emptying time (decreasing tank volume)

Storage time considerations

- Can be minimised by starting fermentation just in time
- Frequent starting stopping upstream processes
- More fermentations / cycle → longer storage
 - $t_{\text{emptying}} - t_{\text{filling}} \rightarrow 0$, shorting filling



CONCLUSIONS

Using gPROMS

- We could easily calculate number and size of fermenters
- Optimise the scheduling of several batch processes in parallel
- Fit the batch fermentation process in a continuous plant

Follow up

- Make implementation plan for gPROMS
- Get budget approval to acquire licence

ACKNOWLEDGEMENTS

Frances Pereira, PSE

Sean Bermingham, PSE